

Processing plant tissues for isotopic analysis of C and N.

1. Grind the samples in agate mortar or ball mil, depending on the amount of sample.
2. Rinse with distilled water and shake in ultrasound bath for 15min.
3. Dry in oven 24 hours (40°C or 50°C).
4. Weight and encapsulated.